ATILLA-750™ QUICK REFERENCE GUIDE

ATILLA-750™ QUICK REFERENCE GUIDE

CAUTION

THERE ARE EYE AND OTHER HAZARDS ASSOCIATED WITH THE USE OF THE ATILLA. READ AND FOLLOW THE ATILLA OPERATOR MANUAL BEFORE USE. NEVER OPERATE THE ATILLA WITHOUT THE PROPER LASER SAFETY TRAINING. NIGHT VISION GOGGLES ARE REQUIRED TO VIEW THE LASER. THE ATILLA IR ILLUMINATOR CAN BE DETECTED BY ANY PERSON WITH A NIGHT VISION DEVICE.

AA BATTERY INSTALLATION

Remove the battery cap. Place two AA lithium batteries into the battery compartment; positive (+) ends first. Replace the battery cap and securely tighten against o-ring.

CONTINUOUS FIRE (CF) BUTTON

Turn the OFF/MODE switch knob to one of the firing modes. Press the continuous fire button to start and stop continuous laser/illuminator laser fire.

USING PADDLE OR REMOTE SWITCH

Ensure that the paddle or remote switch is installed. Turn the OFF/MODE switch knob to one of the firing modes. Press the button on the paddle or remote switch to momentarily fire the aimer/illuminator.

POWER ADJUSTMENT BUTTONS

Turn the OFF/MODE switch knob to one of the visible green laser or IR illuminator firing modes and activate the IR illuminator or visible green laser. Increase and decrease power of the illuminator or aimer by pressing the arrows above and below the light bulb icon.

OFF/MODE SWITCH KNOB

Mode Icon	Fire Mode Description
	Visible Green Laser ON - Steady
	Visible Green Laser ON - Slow Pulse, 1Hz
	Visible Green Laser ON - Fast Pulse, 2Hz
	Illuminator ON - Steady
	Illuminator ON - Pulse

© 2011 Nivisys